

# LSMI-800 High Voltage SMI Interface

## Installation instructions

Instructions de montage


Montageanweisung


Montagevoorschrift

Istruzioni di montaggio

Instrucciones de montaje



Monteringsanvisning





FUSE: F 50mA  
230 V~ 5x20 mm


Date Code



Serial number of the device

### Connectors

EXT	1	GND
	2	B
	3	A
230 VAC 50 Hz	4	Input L line
	5	Input N neutral
SMI	6	I+
	7	I-




4.5 lb-in/0.5 Nm

3 poles: Weidmüller BLZP 5.08/03/180

4 poles: Weidmüller BLZP 5.08/04/180

0.2 - 2.5 mm<sup>2</sup>



This device must not be used with SMI-LoVo engines.

Document 88079801 Web edition

11/2015

Printed in Austria

Data is subject to change

**LOYTEC**  
A Delta Group Company

<http://www.loytec.com>

[support@loytec.com](mailto:support@loytec.com)