



# SmartKey code keypad with integrated reader




The SmartKey code keypad with integrated reader combines the function of a reader and a SmartKey code keypad in one unit.

Arming/disarming is carried out by using the SmartKey key then entering the user code.

## Functions

Initial set-up and operation is the same as with one reader + one code keypad. If required, the SmartKey code keypad can be operated in conjunction with a reader. The SmartKey code keypad with integrated reader can also be used as an autonomous code keypad.



*The reader for the SmartKey key is located in the middle of the unit (not visible from the outside). To operate, hold the SmartKey key in the middle of the SmartKey code keypad (with integrated reader) at a maximum distance of 2 cm.*

The code keypad, used in conjunction with the reader, allows arming and disarming of the intrusion alarm system only after the correct combination of numbers has been entered at the keypad.

Arming/disarming is carried out by using the SmartKey key then entering the user code.

If someone is forced to disarm the intrusion alarm system, a silent alarm (hold-up alarm) can be set off remotely via the code keypad. The code keypad can be surface mounted or flush mounted (outside the secure area).

### Certifications and Approvals

Region	Certification
Europe	CE SmartKey

### Technical Specifications

#### SmartKey code keypad

Operating voltage	12 V (max. 15 V)
LED green	20 mA
LED yellow	20 mA
LED red	2 mA
Buzzer voltage	3 - 15 V
Buzzer current consumption	Max. 13 mA
Environmental conditions	
• Environmental class	3
• Protection category	IP 65
• Operating temperature	-25 °C to +60 °C
• Storage temperature	-25 °C to +60 °C
Cable to control unit	Max. 6 m, permanently cast
Housing	
• Material	ASA Luran S/ABS
• Color	Titanium white (similar to RAL 9010)
Dimensions (H x W x D)	80 x 80 x 30 mm
For installation in 55 mm surface-mounted/flush-mounted junction box	
Weight	0.60 kg

### Ordering Information

**SmartKey code keypad with integrated reader** **4998113948**

Non-contact reader for SmartKey key and user code entry

**Americas:**  
Bosch Security Systems, Inc.  
130 Perinton Parkway  
Fairport, New York, 14450, USA  
Phone: +1 800 289 0096  
Fax: +1 585 223 9180  
security.sales@us.bosch.com  
www.boschsecurity.us

**Europe, Middle East, Africa:**  
Bosch Security Systems B.V.  
P.O. Box 80002  
5600 JB Eindhoven, The Netherlands  
Phone: +31 40 2577 284  
Fax: +31 40 2577 330  
emea.securitysystems@bosch.com  
www.boschsecurity.com

**Asia-Pacific:**  
Bosch Security Systems Pte Ltd  
38C Jalan Pemimpin  
Singapore 577180  
Phone: +65 6319 3450  
Fax: +65 6319 3499  
apr.securitysystems@bosch.com  
www.boschsecurity.com

**Represented by**