# Honeywell



# IDENT-KEY and AC data carrier read-in station



The USB desktop reader can be used for the automatic reading of contactless proX1/IK2 and proX2/IK3/AC data carriers. It is no longer necessary to enter the data carrier code manually by means of the keypad.

The data carrier code can be transferred directly in WINFEM Advanced, WINFEM-User, IQ MultiAccess and IQ SystemControl.

The desired data output format (IK2, IK3/IS and AC) can be selected by means of special commands and will be stored in a non-volatile memory on the USB desktop reader.

When used in combination with WINFEM Advanced (software version V08 or higher), IQ MultiAccess (software version V07 or higher) or IQ SystemControl (software version V02 or higher), the USB desktop reader can be used as a read-in station. The correct data output format will be selected automatically by the respective application. Mis-entries of the data carrier code into the data system are no longer likely.

Irrespective of the application, the USB desktop reader can be used as an input assistance. In this case, the USB desktop reader can be used as a keypad. Depending on the set data output format, the respective data carrier code will be written at the cursor position of the application.

This mode of operation can be used together with the programs WINFEM-User, WINFEM Advanced (software version V07 or previous version), IQ MultiAccess (software version V06 or previous version) and IQ System-Control (software version V01 or previous version).

The USB desktop reader is supplied with voltage by means of the USB interface. Thus the reader needs no additional voltage supply.

# **Performance features**

- Easy installation
- Voltage supply by means of USB interface, no additional power supply required
- Automatic reading of contactless proX1/IK2 and proX2/IK3/AC data carriers
- Optical acknowledgement of reading process by means of DUO LED.
- Program independent operation as input assistance (keypad) e.g. for Office applications
- Non-volatile storage of set data output format
- Compact, shapely housing


#### Support of read-in station

561-MB24/48/100	min. V09 with IS format, equivalent to WINFEM Advanced V08 or higher version	
IQ SystemControl	V02 or higher version	
IQ MultiAccess	V07 or higher version	
In addition, the reader can be used as an input assistance. Re	equirement: "Hyperterminal" (depending on the operating system).	

# Configuration and operation

	🖏 USB Deskte	🖏 USB Desktop-Reader COM port selection		
	COM-Port: Time for read Autostop afte	in: (sec.) r successful reading:	COM3 • 15	
	Ok	Cancel	Read version	Read code format
operties data o	arriers/person			
Data carrier Ro	m/Timezones Switching de	vices		
Number	1	•		
Text	John Doe			
O IK3/IS code	0000000000009636592			
O IK2 code				
• AC code	0000000090300101500	Read in st	ation	
/alidity				
Always valid	~			
Begin Date		*		
End Date		Ψ		
Annually				
PIN				
PIN				
Show PIN				
	wards OK Ca			
Backwards E	wards OK Ca	ancel <u>N</u> ew	data carrier	

Configuration and operation under WINFEM Advanced



Configuration under IQ NetEdit Operation under IQ MultiAccess/IQ SystemControl

# **Technical data**

Operating voltage Current consumption Connecting cable Display Dimensions (W x D x H) Color 5 V DC via USB 35 mA approx. 1.75 m DUO LED green/red 89 x 89 x 16 mm light gray, similar to RAL 7035

#### Order data

Item no. Description

023360 USB desktop reader

Honeywell Security Group Novar GmbH Joh.-Mauthe-Str. 14 · 72458 Albstadt Phone +49 (0) 74 31/801-0 · Fax 801-12 20 www.honeywell.com/security/de info.security.de@honeywell.com

P00660-22-0G0-01 05. 2011 · Subject to change without notice. ©2011 Honeywell International Inc.

